

Installation instruction for PVC ventilation ducts

M/F fitted PVC ventilation ducts

1. Check that the seal is correctly positioned in the groove. If it is not, position it after cleaning the inside of the groove.



2. Mark the length of the M/F fitting on the smooth end of the pipe to be inserted.



3. Apply soap or petroleum jelly only on the lip of the seal and on the end of the pipe to be inserted (Never use grease, it deteriorates the seal)



4. Place the 2 pipes to be inserted opposite to each other. Their axes must be perfectly aligned.



5. Insert the pipe 2-3 cm into the female fitting, stopping just before the seal.



6. Place the 1st SpanSet® around the pipe groove and a second around the pipe to be inserted, without tightening them.



7. Pass a 3rd and 4th SpanSet® in the first 2, on each side of the pipe and along the axes.



8. Tighten the first 2 SpanSet® so as to block the 3rd and 4th SpanSet against the pipes.



9. Now tighten the 3rd and 4th SpanSet® simultaneously so as to fit the pipe to the mark made in step 2. The fitting is now complete.



10. Check with a torch that the sealing joint has not come out of its groove and that the pipe is fully fitted. For large diameter ventilation, you can enter the pipe to perform this verification.

